

227|228|229
NO.5 FLOOR POCKET

117|117|118|118|119|119|120|120|121|121|122|122|123|123|124|124|125|125|126|126|127|127|128|128|129|129|130|130|131|131|132|132|133|133|134|134|135|135|136|136|137|137|138|138
NO.5 SUSPENSION LIGHT

230|231|232
NO.5 FLOOR POCKET

93|93|94|94|95|95|96|96|97|97|98|98|99|99|100|100|101|101|102|102|103|103|104|104|105|105|106|106|107|107|108|108|109|109|110|110|111|111|112|112|113|113|114|114|115|115|116|116
NO.4 SUSPENSION LIGHT

221|222|223
NO.4 FLOOR POCKET

69|69|70|70|71|71|72|72|73|73|74|74|75|75|76|76|77|77|78|78|79|79|80|80|81|81|82|82|83|83|84|84|85|85|86|86|87|87|88|88|89|89|90|90|91|91|92|92
NO.3 SUSPENSION LIGHT

224|225|226
NO.4 FLOOR POCKET

215|216|217
NO.3 FLOOR POCKET

47|47|48|48|49|49|50|50|51|51|52|52|53|53|54|54|55|55|56|56|57|57|58|58|60|60|61|61|62|62|63|63|64|64|65|65|66|66|67|67|68|68
NO.2 SUSPENSION LIGHT

218|219|220
NO.3 FLOOR POCKET

209|210|211
NO.2 FLOOR POCKET

24|24|25|25|26|26|27|27|28|28|29|29|30|30|31|31|32|32|33|33|34|34|35|35|36|36|37|37|38|38|39|39|40|40|41|41|42|42|43|43|44|44|45|45|46|46
NO.1 SUSPENSION LIGHT

212|213|214
NO.2 FLOOR POCKET

NO.1 FLOOR POCKET

NO.1 FLOOR POCKET

203|204|205

206|207|208

1|1|2|2|3|3|4|4|5|5|6|6|7|7|8|8|9|9|10|10|11|11|12|12|13|13|14|14|15|15|16|16|17|17|18|18|19|19|20|20|21|21|22|22|23|23
APRON LIGHT

22,080

147|147|148|148|149|149|150|150|151|151|152|152|153|153|154|154|155|155|156|156|157|157|158|158|159|159|160|160|161|161|162|162
CEILING LIGHT

139
139
140
140
141
141
142
142

FRONT SIDE LIGHT


143
143
144
144
145
145
146
146

FRONT SIDE LIGHT

163|163|164|164|165|165|166|166|167|167|168|168|169|169|170|170|171|171|172|172|173|173|174|174|175|175|176|176|177|177|178|178|179|179|180|180|181|181|182|182
NO.1 CEILING LIGHT

183|183|184|184|185|185|186|186|187|187|188|188|189|189|190|190|191|191|192|192|193|193|194|194|195|195|196|196|197|197|198|198|199|199|200|200|201|201|202|202

NO.2 CEILING LIGHT



SOUND REF' DOWN LIGHT 233|234|235 (238)
AUDITORIUM LIGHT 237|238|239|240