

75 76 75

NO.2 WALL POCKET (DIM 3CIR)

51 52 53 54

UPPER HORIZONT (DIM 4CIR)

76 75 76

NO.2 WALL POCKET (DIM 3CIR)

DMX4 42 43 44 45 46 47 48 49 50

NO.4 SUSPENSION (DIM 6CIR, DMX1)

DMX3 28 29 30 31 32 33 34 35 36 37 38 39 40 41

NO.3 SUSPENSION (DIM 18CIR, DMX1)

DMX2 19 20 21 22 23 24 25 26 27

NO.2 SUSPENSION (DIM 6CIR, DMX1)

73 74 73

NO.1 WALL POCKET (DIM 3CIR)

DMX1 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18

NO.1 SUSPENSION (DIM 18CIR, DMX1)

74 73 74

NO.1 WALL POCKET (DIM 3CIR)

DMX5 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72

CEILING (DIM 18CIR, DMX1)

HOUSE LIGHT 77 78 RD1 RD2 RD3